

GRAVITY BOMB

CLEAN BOOST & MIDS ENHANCER

BOOST

Controls the output level of the boost.

9-18V

Standard 2.1mm x 5.5mm center-negative power input. Running Gravity Bomb at 18V will yield greater headroom.

IN/OUT

Standard 1/4" Instrument cable. Input on the right, Output on the left.



MIDS



In the up position, mids are boosted at 1kHz.



In the middle position, mids control is off and Gravity Bomb is flat.



In the down position, mids are boosted at 750Hz.



10mA @ 9V | 20mA @ 18V Consumption

IN/OUT: 1/4" Instrument Cable